



WIRE-N-USB-R

802.11 N USB Wireless Adapter


Quick Installation Guide

Package Contents	Page	1
Network Card Installation	Page	2
Connect to Wireless Access Point	Page	5

Package Contents

Before you starting to use this wireless network card, please check if there's anything missing in the package, and contact your dealer of purchase to claim for missing items:

USB Wireless Network Card (1 pcs)	1
Protection Cap (1 pcs)	2
Ouick Installation Guide (1 pcs)	3
Driver/Utility/User Manual CD-ROM (1 pcs)	4



WPS setting

WPS (Wifi Protected Setup) enables to have an automatic and secure WIFI connection: a simple pressure on the button lets you connect to Wireless network without additional setting, nor password setting. It can run only with router or modem equipped with WPS button no matter what trademark is

trademark is.

- The setting is simple and easy:

 -After creating wireless secure network on your box/router/modem-router
 (consult the device manual), press down the WPS button.


 -Press down the WPS button of the wireless USB device.


 -The 2 devices will automatically synchronize instantly: you just have to wait.

 -You will be automatically connected to your secure wireless network.

Network Card Installation

Please follow the following instructions to install your new USB wireless network








Connect to Wireless Access Point

Using Configuration Utility to Connect to Wireless Access Point:



After installation is complete, wireless configuration utility will be shown in the desktop of your computer automatically. You will also see an icon at the lower-right corner of your windows system. You can click the icon by right mouse key, and select the configuration utility.



2. Configuration utility will scan for wireless access points and access to any unencrypted wireless access point automatically. If you wish to connect to another access point, select the access point and double click it.

If the wireless access point you want to connect does not show here, please click 'Rescan'.



3. If the wireless access point uses encryption, you have to input WEP key or WPA preshared key. Please ask the owner of the wireless access point you want to connect and input the correct key here, and then click 'OK'. If the value you inputted here is wrong, you will not be able to connect to wireless access point.



4. If the wireless access point is successfully connected, you'll® see a symbol appears in front of the name of wireless device.

For advanced settings and other features of this USB wireless network card, please refer to user manual enclosed in supplied CD-ROM.

F© (E1)

Copyright © 2009, Connectland, All rights reserved

6